




Owners manual



PREFACE

You have purchased our scooter, congratulations and thank you for putting your trust in us.

This model is a sturdy scooter in modern design.

Its sound construction, the meticulous selection of materials, the advanced manufacturing techniques and conscientious work of dedicated employees provides the scooter with all the characteristics such as economical operation, quality, reliability and its lasting value.

We cannot be held liable for any consequential damage caused by accessories not approved by the factory.

The scope of delivery and version of the scooter is solely determined by the purchase agreement concluded with the dealer.

This operating manual includes important instructions for handling your light scooter. Read it carefully, because professional handling combined with regular care and maintenance helps to maintain the scooter's value and is one of the requirements for warranty claims.

We wish you at all times a safe journey.

Yours

Safety symbols and notes

Please observe the following:

WARNING

Precautionary measures against the risk of accidents, injury and /or death.

FIRE HAZARD


The vehicle is equipped with a catalyst, this results in extremely high temperatures on the exhaust system (risk of burning)

CAUTION

Important instructions and precautionary rules to avoid damage to the vehicle. Nonobservance can lead to the warranty becoming void.

NOTE

Special instructions for better handling during operation, inspection adjustments and service activities.



CONTENTS

OVERVIEW AND OPERATION

| | |
|---|-----|
| Identification number, engine number..... | 3 |
| View of vehicle..... | 4-5 |
| Instrument, handlebar instrument..... | 6 |
| Ignition lock and fork-column lock..... | 7 |
| Storage box, luggage hooks..... | 8 |
| Fuel, fuel tank..... | 9 |
| Tank cap..... | 10 |
| Side stand, parking stand..... | 11 |

SAFETY TEST

| | |
|----------------------|----|
| Checklist..... | 12 |
| Load and lights..... | 13 |
| Ride safely..... | 13 |

RIDING INSTRUCTIONS

| | |
|--|-------|
| Ride economically and environmentally..... | 14 |
| Running-in instructions..... | 15 |
| Starting..... | 16-17 |
| Brakes..... | 18-19 |
| Stopping the engine..... | 19 |

SERVICE INSTRUCTIONS

| | |
|---|-------|
| Servicing the scooter / cleaning agents..... | 20-21 |
| Winter operation and corrosion protection..... | 21 |
| Repairing paint damage / servicing the tyres..... | 22 |
| Lay-up commission..... | 22 |
| Technical modifications, accessories and spare parts..... | 23 |

CONTENTS

NOTES ON MAINTENANCE

| | |
|--|-------|
| Engine oil..... | 24-26 |
| Transmission oil..... | 26 |
| Checking steering bearing, telescopic fork..... | 27 |
| Tyres..... | 28 |
| Front wheel brake..... | 29-30 |
| Rear wheel brake..... | 31 |
| Adjusting the play of the twist grip throttle control..... | 32 |
| Cleaning the air filter..... | 33 |
| Cleaning the spark plug..... | 34 |
| Fuse..... | 35 |
| Battery..... | 36-37 |
| Changing the light..... | 38-42 |
| Adjusting the headlight..... | 43 |
| Fault diagnosis tester..... | 44 |

TECHNICAL DATA


| | |
|--------------------------------------|----|
| Engine..... | 45 |
| Power transmission..... | 46 |
| Chassis..... | 46 |
| Lubricants and operating fluids..... | 47 |
| Electrical equipment..... | 47 |
| Dimensions and weights..... | 48 |

WARRANTY AND SERVICE DATA


| | |
|---------------------------|-------|
| Warranty conditions..... | 49 |
| List of wear items..... | 50-51 |
| Inspection items..... | 52-54 |
| Proof of maintenance..... | 55-56 |
| Circuit diagram..... | 57 |

SUMMARY AND OPERATION


Identification number



Chassis number



Engine number



NOTE

The description for right-hand side is viewed from the driver.

The identification number (1) is located on the rear part of the frame below the right underside cover.

The chassis number is located on the frame behind the cover (2).

The engine number (3) is located on the front part of the left crankcase.

Key

With the scooter you get two separate indefinite keys for:

- Ignition lock, storage box.

Keep the spare key at a safety place.

OVERVIEW AND OPERATION

Right-hand side view

- 1 Storage box with tool kit
- 2 Spark plug
- 3 Engine oil filter cap
- 4 Battery box and fuse
- 5 Ignition and fork-column lock
- 6 Brake fluid container for front wheel brake
- 7 Handbrake lever for front brake



OVERVIEW AND OPERATION

Left-hand side view


- 8 Handbrake lever for rear brake
- 9 Instrument
- 10 Kick starter
- 11 Parking stand
- 12 Transmission oil filler screw
- 13 Air filter
- 14 Side stand






OVERVIEW AND OPERATION

Instrument







- 1 Speedometer km/h/mph
- 2 Odometer km
- 3 Fuel indicator 

Instrument lights


- 4 Left and right direction indicator  green
- 5 High beam indicator  blue
- 6 Malfunction Indicator Lamp  orange


Handlebar instrument, left




- 1 Fixed grip
- 2 Handbrake lever for rear brake
- 3 Direction-indicator switch
 - ⇐ Switch to left
Left indicator on
 - ⇒ Switch to right
Right indicator on
 - Push button for switch off
- 4  Push-button:horn
- 5 High beam indicator
 -  high beam
 -  low beam

Handlebar instrument, right




- 6 Handbrake lever for front brake
- 7 Throttle
- 8  Starter button

Ignition and fork-column lock



WARNING

While riding, do not switch the ignition off !

NOTE



Keys

With the scooter you get two indefinite ignition keys. Keep the spare key at a safety place.

Key positions



NOTE

The key can be removed in positions  and .



(1) Operating position

Ignition and all circuits activated.




(2) Ignition off

Fork column not locked (handlebars can be freely turned to the left or right).



(3) Fork column locked and ignition off


Turn the handlebar to the left as far as to the stop.

Push and turn the key to the left until it is in the LOCK  position. The fork column is now locked.

OVERVIEW AND OPERATION

Storage box

- Do not store valuables in the box.
- Make sure that the seat has been locked completely after it was pressed down.
- Take out valuables before washing to avoid wetting these objects.
- Do not place thermal sensitive objects in the box because of engine's heat and high temperature.



Unlock

- Insert the ignition key (1) into the lock and turn the key to the right.

Lock

- Press down the seat (2) until the lock is engaged.
 - Pull out the ignition key.
- Never leave the key in the storage box.



WARNING

After the seat is closed check if it was locked firmly! -Risk of accidents!

Maximum load capacity: 10 kg

Luggage hooks



Use the hooks (3) only for small baggage pieces.



CAUTION

Maximum load capacity: 1.5 kg
Do not transport bulky loads.

OVERVIEW AND OPERATION

Fuel, fuel tank


WARNING

Fuel is highly inflammable and can explode. Do not smoke or bring a naked flame near the fuel tank.

Fuel expands under the influence of heat and the sun. Therefore, never fill the tank to the brim. Never fill the tank while the engine is running.


Never bring a glowing cigarette or naked flame near an open tank, because fuel vapour could suddenly ignite.

Fuel



NOTE

The fuel indicator (1) is active when the ignition is turned on.

The scale with the tank symbol  remembers for petrol refill.

E = Empty

F = Full

Don't run down the fuel tank until it is empty.

Filling up with fuel




- Use only premium lead-free fuel (min.95 octane)

Malfunction Indicator Lamp

- When the fault light (2) flashes, indicating that the electronic control system failure, please check with the local dealer.

OVERVIEW AND OPERATION

Tank cap



NOTE

The tank cap is designed with ventilation. Do not make any changes to the cap.

Unlock:

- Tilt up the cover (1).
- Insert ignition key (2) .turn to direction OPEN and open the tank cap.

LOCK:

- Close the tank cap by turning with the ignition key to direction CLOSE and pull out the key.



NOTE

After fill the fuel and put the fuel tank cap back, please point the triangle sign (3) of the fuel tank cap to the triangle sign (4) on the rear center cover.



NOTE




Fuel

Euro IV version: (E5)

Other version: Unleaded fuel min. 95 Octane

OVERVIEW AND OPERATION

Side stand and parking stand



Propping up the scooter on the side stand.

WARNING

Always make sure that the stand is resting on firm ground. On sloping roads, always park the scooter facing uphill. It is essential that the side stand is folded up before starting off ! -Risk of accidents!

Side stand



NOTE

The scooter is equipped with a side stand switch. If the side stand is folded up the engine is shut off and will not start.

- Switch off the engine.
- Put your left hand on the left-hand handle-bar grip.
- Hold the holder grip with your right hand (3).
- Fold out the arm of the side stand(1) as far forward as it will go and stop by foot.
- Slowly tilt the scooter to the left until its weight is supported.

Parking stand

- Switch off the engine.
- Put your left hand on the left-hand handle-bar grip.
- Hold the holder grip(3) with your right hand.
- Push the parking stand (2) down until the two skids are on the ground.
- Put your full body weight on the operating mandrel of the main standard.
- Pull the scooter towards the rear and simultaneously upwards onto parking stand.
- Check that the scooter is standing firmly.

SAFETY TEST

Checklist

Before each ride, carry out a safety check using the checklist.

Take the safety check seriously. Carry out maintenance activities before you start your ride or ask a specialized dealer to do so.

This will provide you with the certainty that your motorcycle corresponds to traffic regulations. A technically faultless motorcycle is a basic requirement for the safety of both yourself and other road users.

Before starting your ride, check the following:

- Steering (smooth and free play)
- Engine oil quantity
- Fuel quantity
- Front brake
- Rear brake
- Tyres (profile and pressure)
- Telescopic fork
- Load / lights
- Total weight
- Lights
- Brake fluid (lever)
- Brake (operation)

In case of problems or difficulties, contact a dealer, who will do everything possible to assist you.



WARNING

While the engine is running or the ignition is on, do not touch the ignition system.



FIRE HAZARD

The exhaust system becomes very hot. While riding, idling or parking, make sure that no inflammable materials (e.g. hay, leaves, grass, coverings or luggage, etc.) can come into contact with it!

SAFETY TEST

Load / lights

WARNING

For the sake of your safety, use only original accessories or products released by us.

We cannot judge for each third-part product whether it can be safely used in combination with your scooter.

Nor can an official approval give such a guarantee in all cases, since the test scope is not always sufficient.



NOTE

Our accessories and approved products as well as qualified advice are available from all specialized dealers.

Correctly loaded

- Make sure that the left-right weight distribution is balanced.
- Check that fastenings are correct and tight.
- Do not transport bulky loads.
- Do not cover the lights.

WARNING

The total allowable weight may not be exceeded.

Check the tyre pressure.

Checking the lights

WARNING

Before any ride, check the operation of all lighting components.

- Check that the headlamps and lenses are clean.

Ride safely



CAUTION

Riding safety is largely also determined by the manner of riding.

Therefore:

- Put on a tested / approved safety helmet and correctly close the buckle.
- Wear suitable protective clothes.
- Rest your feet on the footrests.
- Do not ride if your riding ability has been compromised.

Your reactions can be adversely affected not only by alcohol, but also by drugs and medicines.

- Strictly observe all traffic regulations.
- Always adapt your riding speed to the traffic and road conditions.

On smooth, slippery roads take into account that your riding stability and braking power are limited by the grip of the tyres on the road top.

RIDING INSTRUCTIONS

Ride economically and be aware of the environment

Fuel consumption, environmental pollution and wear of engine, brakes and tyres depend on various factors.

Your personal riding style is highly determinant for economical fuel consumption and exhaust gas and noise generation.

While idling, the engine takes a long time to warm up to operational temperature.

Avoid rapid acceleration

Open the throttle not further than needed, in order to reduce fuel consumption as well as pollution and wear levels.

Do not use excessive revs; change up as soon as possible and do not change down until it is necessary to do so.

Ride as evenly as possible and look ahead as far as possible.

Unnecessary acceleration and hard braking cause high fuel consumption and increased pollution levels.

Different riding conditions affect fuel consumption. The following conditions are unfavourable for fuel consumption:

- High traffic density, especially in big cities with many stops for traffic lights.
- Frequent short rides with repeated starts and warm-ups of the engine.
- Riding in a column of motorcycles at low speed, meaning riding with relatively high revs.

Plan rides ahead of time in order to avoid heavy traffic.

Fuel consumption is also affected by conditions that are out of your control, for instance, poor road condition, hills, riding in winter.

Observe the following aspects for economical fuel consumption:

- The planned inspection intervals must be closely observed.
- Regular service by a specialized dealer will guarantee not only continued operability, but also economical fuel consumption, low environmental pollution and a long lifespan.
- Check the tyre pressure every two weeks.

Low tyre pressure increases rolling resistance. This increases fuel consumption and tyre wear and adversely affects riding behaviour.

- Continually check fuel consumption.
- Frequently check the engine-oil level.

RIDING INSTRUCTIONS

Running-in

Running-in instructions for engine and transmission.



CAUTION

Excessive revs while running-in the engine increases the wear of the engine. Engine faults during the running-in period must be immediately reported to a specialized dealer.



NOTE

During the running-in period, ride in frequently changing load and rpm ranges. Select winding and slightly hilly routes. Avoid constantly low rpm counts and full throttle under load.

- During the first 500 km:
Less than 1/2 throttle.

- Up to 1.000 km:
Less than 3/4 throttle.



CAUTION

The first inspection must be carried out immediately after the first 1.000 km.

You can save yourself delays by making an appointment with a specialized dealer in advance.

Running-in new tyres



CAUTION

New tyres have a smooth surface. They must therefore be roughened by carefully running them in at various slanted positions.

Only then will the surface obtain its full grip!

Running-in new brake linings



WARNING



New brake linings must be run-in and will not have their full friction power until after 500 km.

The slightly reduced braking effect can be compensated for by an increase in the pressure on the brake lever.

During this period, avoid unnecessary hard braking actions.

RIDING INSTRUCTIONS

Starting with the electric starter



WARNING

Propping up the scooter with the parking stand. Operate the rear handbrake lever to avoid a moving of the scooter. Avoid high engine rpm's while the vehicle is standing still, otherwise the clutch will engage.



NOTE

Every scooter is equipped with side stand switch. When the side stand is fold up, can start the engine. When the side stand is released, can't start the engine.

Before starting

- Propping up the scooter with the parking stand.
- Turn the ignition lock (1) with the ignition key to its operating position ↻.
- Do not open the throttle (3).
- Pull and hold the handbrake lever (2).
- Operate the start button (4).
- If the engine can not be started after the starter motor is running for 3-5 seconds, open the throttle (3) 1/8-1/4 turns and start again.
- Push the scooter off its parking stand.
- Mount the scooter.
- Release the brake before riding.




CAUTION

If the engine won't start immediately, release the start button, wait a few seconds and push it again. Each time, push the start button for just a few seconds in order to save the battery. Never push the start button for more than 10 seconds.

WARNING


Never allow the engine to run in an enclosed space. Exhaust gases are highly toxic and can kill.

Starting with kick starter



CAUTION

After starting the engine, check that the kick starter lever (3) is returned to its normal position.

- Propping up the scooter when operating the kick starter.
- Turn the ignition lock (1) with the key to its operating position .
- Do not open the throttle (2).
- Depress the kick starter lever (3) quickly and the engine will start.
- After the engine is running return the kick starter lever to its normal position.



NOTE

Use the kick starter from time to time to maintain its function.

RIDING INSTRUCTIONS

Braking

Wet brakes

Washing the scooter or riding through water or rain can delay the braking effect due to wet or (in winter) ice-covered brake discs and linings.

WARNING

The brakes must first be operated until they are dry.

Salt film on the brakes

When riding on salted streets without braking for a while, the full braking effect may be delayed.

Oil and grease

WARNING

The brake discs and linings must be free of oil and grease!

If the scooter is not used for a while , a rust film may form on the brakes and thus increase the braking effect. A thick rust film can cause the brakes to lock up. When setting out on a ride after a long lay-up period, carefully operate the brakes several times until they work normally.



NOTE

Make sure you practice braking for emergency situations, but do so where you will not pose a risk to yourself or others(e.g.a deserted parking area).

WARNING

Operate the brakes to grind off the salt deposited on the brake discs.

Dirty brakes



When riding on dirty streets, the braking effect can be delayed due to dirty brake discs and linings.

WARNING

Operate the brakes until they are clean. Lining wear is increased by dirty brakes!

RIDING INSTRUCTIONS

Braking



Braking

The front brake and rear brake are operated independently from each other. The front brake is operated via the right-hand brake lever(1)on the handlebars,and the rear brake is operated via the left-hand brake lever(2).


When stopping or slowing down,release the throttle gas and operate **both** brakes at the same time.


On tight curves, sandy / dirty streets, wet asphalt and icy roads,use the front brake carefully: if the front wheel locks , the bike will slide sideways.

Brake with care.Locked wheels do not have much braking effect and can lead to skidding / crashing. In principle,do not brake on a curve, but before the curve.

Braking on a curve increases the danger of sliding.

Stopping the engine



- Turn the ignition lock (3) with the ignition key to the position .
- Pull out the ignition key.

SERVICE INSTRUCTIONS

Servicing the scooter / cleaning agents




NOTE

Regular, expert service will help maintain the value of your scooter and is a condition for guarantee claims for corrosion and other such damage.



CAUTION

Rubber and plastic parts will be damaged by caustic or penetrating cleaning agents or solvents.




WARNING

Always carry out a brake test after cleaning and before starting a ride!



CAUTION

Do not use steam or high-pressure jet devices! Such devices can damage seals, the hydraulic braking system and the electrical system.




CLEANING

- To wash the motorcycle, use a soft sponge and clean water.
- Afterwards, dry off with a polishing cloth or chamois.
- Do not wipe off dust or dirt with a dry cloth, to avoid scratching the paint or covering.

SERVICE INSTRUCTIONS

Servicing the scooter / cleaning agents



PRESERVATION AGENTS

When necessary, the scooter must be preserved with commercially available preserving and cleaning agents.

- By way of precaution (especially in winter), regularly treat parts liable to corrosion with preservation agents.



CAUTION

Never use paint-polishing agents on plastic parts.

- After a longish ride, thoroughly clean the chassis and the aluminium parts and preserve them with a commercially available anti-corrosion agent.

Operation in winter and anti-corrosion protection



NOTE

Protect the environment by using only environmentally friendly preservation agents, and use them frugally.

Use of the motorcycle in the winter can cause considerable damage due to the presence of salt on the roads.




CAUTION

Do not use hot water, which would increase the effect of the salt.

- At the end of each ride, wash the motorcycle with cold water.
- Thoroughly dry the motorcycle.
- Treat parts liable to corrosion with waxborne anti-corrosion agents.

SERVICE INSTRUCTIONS

Repairing paint damage



Minor paint damage should be immediately repaired.

Servicing tyres

If the scooter is not used for a longer period, it is recommended to support the scooter so that its weight is not on the tyres. You can prevent the tyres from becoming dry and brittle by spraying them with a silicone-rubber treatment. First thoroughly clean the tyres.

Do not store the scooter or the tyres in hot spaces (such as a boiler room) for longer periods.

WARNING

A minimum tyre-profile depth of 2.0 mm must be maintained at all times.

Lay-up / commission

Lay-up

- Clean the scooter.
- Remove the battery. Observe the maintenance instructions.
- Spray suitable lubricants onto the brake lever, clutch lever joints, the side standard and main-standard bearings.
- Rub bright / chromium-plated parts with acid-free grease (Vaseline).
- Store the scooter in a dry room and jack it up so that its weight is not on the wheels.



NOTE

Combine lay-up / commission activities with an inspection by a dealer.

Commission

- Remove the preservation agents from the outside.
- Clean the motorcycle.
- Install the charged battery.
- Preserve the battery terminals with terminal grease.
- Check / adjust the tyre pressure.
- Check the brakes.
- Carry out activities according to the inspection plan.
- Carry out the safety checks.

SERVICE INSTRUCTIONS

Technical changes, accessories and spare parts

WARNING

Technical changes to the scooter can lead to invalid warranty.

Should you want to make technical changes, observe our guidelines. This will serve to prevent the scooter from being damaged and the traffic and operational safety being retained. A specialised dealer can carry out these activities with meticulous care.

Always consult a dealer before buying accessories or making any technical changes.



CAUTION

We recommend using only approved accessories and original spare parts for our scooter.



This is in your own interests : the safety, suitability and reliability of these accessories and parts will have been tested specifically for the scooter.

Although we keep track of the market, we neither can evaluate nor be held liable for the quality of non-approved accessories and parts , even if they have a certificate of acceptance from an officially recognised technical testing / supervision agency, or a license issued by the authorities.

For approved accessories and original spare parts, see a specialised dealer. He will also ensure that they are professionally installed.

NOTES ON MAINTENANCE

Engine oil



Checking the oil level



CAUTION

Checking the oil while the engine is cold will lead to a wrong measurement and therefore the wrong oil quantity. In order to avoid engine damage, neither exceed the maximum oil level nor let it drop below the minimum level.



NOTE

Make sure that the scooter during oil-level checks stands level in all respects. Even the slightest inclination towards the side will produce measurement errors.

- Stop the warmed-up engine, wait for approx. 5 minutes and hold the scooter up-right.
- Keep the scooter vertical with two wheels on the ground.
- Stop the engine and remove the oil filler cap (1) on the lower right of the crank-case.
- Clean the oil filler cap at the MIN-MAX area with a clean rag.



CAUTION


For checking the oil level only insert the oil filler cap and don't screw in! Otherwise there will be a wrong measurement in order to avoid engine damage.

- The oil level must be between the minimum and maximum marks.
- Tighten the oil filler cap by hand.

If required, replenish the engine oil SAE 15 W/40 via the oil level up to the MAX level mark.

- When change new engine oil, open the oil hole screw (2), till all engine oil is flow out, then tighten the screw (2) and add new oil until the oil level up to the MAX. level mark.
- Tighten the oil filler cap (1).

Engine oil



CAUTION

Do not use additives . Since the oil also serves to lubricate the clutch, do not use car engine oils supplemented with friction modifiers (such energy-conserving oils can lead to the clutch slipping). Use a suitable, light engine oil for scooters , such as Motorex SAE 15W/40 mineral oil API (SJ or higher).

- If required, replenish the engine oil(for classification and viscosity, see the table) via the oil-filler opening up to the maximum level marking.

Clean oil filter element


If the oil filter element is also to be replaced or cleaned, perform the following procedure.

- Remove the oil strainer cover (1), spring (3) and oil filter element(2).
- Replace the O-ring (4) new.
- Install the new or clean oil filter element and the oil strainer cover.

Install torque:13-17 N.m

NOTES ON MAINTENANCE

Engine oil




Recommended grade:

Per API: SJ or higher or also with additional release status: ACEA A3/96 (CCMC G5)

Recommended viscosity:

Viscosity depends on the outside temperature. For short while, the temperature may exceed or fall short of the limits of the SAE grades.

The recommended viscosity grade SAE 15W/40 covers the ambient temperature range -15°C to +40°C and therefore represents the optimum for our latitudes.



Checking the transmission oil level

- Stop the warmed-up engine, wait for approx. 5 minutes.
- Propping up the scooter on the parking stand.
- Remove the oil filler screw (1) and check if the oil level is below the oil-filler opening.
- If required, replenish transmission oil Hypoid SAE 80W-90 via the oil-filler opening.
- When change new transmission oil, open the oil hole screw (2), till all transmission oil is flow out, then tighten the screw (2) and add new oil via the oil-filler opening.
- Tighten the oil filler screw (1).

NOTES ON MAINTENANCE

Checking the steering bearings



NOTE

The telescopic fork should not jam up when turned and it should swing back lightly to both end positions.

- Pull the hand brake to block the front wheel brake.
- Hold the handlebar with both hands and try to move the handle bar(1)back and forth.

If the fork column bearing shows noticeable play, it must be adjusted by a specialised dealer.

Checking the telescopic fork

- Pull the hand brake to block the front wheel brake.
- Now pump the fork girders several times up and down using the handlebar.
- The suspension should respond perfectly.
- Check the fork girders for oil leaks.




NOTE

If damage to the telescopic fork or the spring strut is found have the motorbike examined by a professional dealer.

NOTES ON MAINTENANCE

Tyre profile



Checking the tyre profiles

WARNING

Observe the minimum profile depth prescribed by law.

Never ride without valve caps(1) . Firmly tightened valve caps prevent the tyre from suddenly losing pressure.

- Measure the profile depth at the centre (2) of the tyre's tread.

Recommended minimum profile depth:
2.0 mm

Observe the wear marks(3).

Checking the tyre pressure

WARNING

Adjust the tyre pressure according to the total weight load. Never exceed the rated total weight or the bearing capacity of the tyres.

Incorrect tyre pressure will have a considerable effect on the riding properties of the scooter and the lifespan of the tyres.

- While the tyres are cold:
- Twist off the valve caps.
- Check / adjust the tyre pressure.
- Twist on the valve caps.

Tyre pressure

One Rider: Front: 1.75Kg/cm² Rear: 2.00Kg/cm²

Two Rider: Front: 2.00Kg/cm² Rear: 2.25Kg/cm²

Tyre size

The standard scooter is provided with the following tyre sizes:

| | |
|-------|--------------------|
| Front | 3.50-10 51J or 59P |
| Rear | 3.50-10 51J or 59P |


All Tyres are tubeless.

WARNING

Use only tyres approved by the manufacturer. The use of non-approved tyre brands, types or sizes leads to the operating permit of the vehicle becoming null and void. Use only pairs of tyres produced by the same manufacturer.

NOTES ON MAINTENANCE


Front wheel brake



⚠ WARNING

Sudden changes in play or a spongy feel of the brake lever (1) can be caused by faults in the hydraulic system. Do not ride on when in doubt about the operability of the brake system. Immediately consult a dealer.

Front brake-fluid tank



Checking the brake-fluid level

⚠ WARNING

Every two years, the brake fluid must be changed by a dealer. The level must not drop below the MIN mark. Use only brake fluid of the DOT 4 classification.




CAUTION

Do not spill any brake fluid on painted or plastic surfaces as it will damage the surface severely.

- Turn the handlebars until the brake-fluid tank (2) is level.
- The brake fluid level(3) should be between the minimum (MIN) and the maximum marking (MAX).
- If air bubbles can be seen, check the brake linings for wear; if necessary, replenish the brake fluid by a dealer.

NOTES ON MAINTENANCE

Front wheel brake



Checking the brake linings



CAUTION

The minimum lining thickness must be maintained




NOTE

For your own safety, we recommend having activities to the brake system carried out by a dealer.

- Check the thickness of the brake lining.

Minimum thickness: **A = 2.0 mm**

- If the lining thickness is below the minimum, **have the brake lining (1) replaced by a dealer.**



Checking the disc brake




- Visually inspect the disc (2).

- Check the thickness of the disc.

Minimum thickness: **B = 3.0 mm**

- If the disc thickness is below the minimum, **have the disc (2) replaced by a dealer.**

Rear wheel brake



Adjusting the rear wheel brake



CAUTION

For your own safety, we recommend having activities to the brake system carried out by a dealer.



NOTE

After a longer period of operation, adjustment of the brakes is essential due to natural wear of the brake-shoe linings.

Checking

- An external sign of the brakes needing adjustment is the constantly increasing free travel (A) of the handbrake lever (1) 10-20 mm.

Adjusting

- Screw the nut (2) on the rear-wheel brake onto the brake rod until the handbrake lever reach a free travel of 10-20 mm.
- After this measurement is attained, the brake shoes should be heard brushing against the brake drum.



CAUTION

Have a dealer check the adjustment. Checking the brake linings.



CAUTION

The thickness of the brake lining may not be lower than the minimum value.

Operate the handbrake lever(1) and visually inspect it.



Check the thickness of the lining:

The extension of the wear indicator (3) at the brake lever must be in front of the minimum mark of the scale(4) when the rear brake is depressed.

If the thickness of the lining has fallen below the minimum, have a specialised dealer replace it.

NOTES ON MAINTENANCE

Adjusting the play of the twist grip throttle control



Check:

- Check the throttle cable for light movement by turning the twist grip (1) from closed to open position.
- Move the handlebar to check whether the throttle cable moves freely.
- Check whether the throttle cable is obstructed by other parts.
- Open the twist grip throttle control until resistance can be felt.
- Measure the play.
Nominal value: **A = 3-5 mm**

Adjustment:




- Push back the protective cap (2).
- Slacken the lock nut (3) on the handlebar.
- Turn the setscrew (4) accordingly.
- Tighten the lock nut (3).
- Check the play.
- Push over the protective cap (2).



NOTE

If the play cannot be corrected this way, have the scooter checked by your dealer.

Cleaning the air filter



Check and change



NOTE

The scooter is attached with an air filter. In case of heavy dirtiness the paper filter element (3) has to be replaced.

- Remove the screws (1) and take off the air filter cover (2).
- Take off the paper filter element (3).
- Dust out the paper filter and clean with air pressure or renew if necessary.



NOTE

- Usually the installation takes place in reverse order to disassembly.



CAUTION




Never run the engine without air filter.

- Dust deposit is one of the major causes of reducing output horsepower and increasing fuel consumption.
- Change the air cleaner element more frequently to prolong the engine's service life if the scooter is ride on dusty roads very often.
- Check for properly installation of the paper filter element housing in the filter case.
- Otherwise the engine runs poorly or lead to serious engine damage.
- Be careful not to soak the air cleaner when washing the scooter. Otherwise it will cause engine hard to start.

The air inlet of oil-gas separator (4) connects with cylinder breath pipe, air outlet connects with air filter port, oil discharge outlet should face to the ground. If there's too much oil in the oil discharge pipe, please release the oil and check the oil measure tape if the engine oil is enough.

NOTES ON MAINTENANCE

Checking the spark plug



Check and change



CAUTION


Check or change the spark plug only when the engine is cold.

- Insert the ignition key (1) into the lock and turn the key to the right, open the seat (2).
- Remove four nuts (3) with the storage.
- Take off the storage (4) with the seat.
- Pull the spark plug connector (5).
- Unscrew the spark plug with the spark wrench from the on-board toolkit.
- Check the electrode gap (0.6-0.7mm) replace the spark plug if it is severely burnt away.
- Use a new spark plug **NGK CR7HSA** and tighten up.




- Screw in the spark plug by hand and then tighten up with the spark wrench.

Torque 11 Nm.

Installation takes place in reverse order to disassembly.



Checking the fuse





CAUTION

Never install a fuse with a larger rating, since this could destroy the entire electrical system.

The fuse is located behind the inspection cover (3).

- Turn off the ignition.
- Take off the plastic footrest cover (1).
- Remove the four screw(2)and open the inspection cover (3).
- Open the fuse case (4) and remove the fuse.
- A faulty or blown fuse must be replaced by a new one with 15 A.
- Check the fuse for correct contact. Loose fuse will blow.

Installation takes place in reverse order to disassembly.



NOTES ON MAINTENANCE

Battery



WARNING

Always wear safety glasses.
Keep children away from acids and batteries.



EXPLOSION DANGER

A battery being charged produces a highly explosive gas, which is why fire, sparks, naked flames and smoking are prohibited.



FIRE HAZARD

Avoid generating sparks and electrostatic discharges when handling cables and electrical devices.
Avoid short circuits.



DANGER-CAUSTIC ACTION

Battery acid is highly caustic, so always wear safety gloves and glasses.
Do not tilt the battery as acid can leak from the ventilation openings.



FIRST AID

If acid comes into contact with an eye, immediately flush the eye for several minutes with fresh water. Then immediately visit / call a doctor.

Acid on the skin or clothing must immediately be neutralised using acid converter or soap suds, and the spots must be flushed with plenty of water.

If acid is swallowed, immediately visit / call a doctor.



CAUTION

Do not expose batteries to direct sunlight. Discharged batteries can freeze, so they must be stored in a place where the temperature remains above 5-15°C.

Professional maintenance, charging and storage will increase the lifespan of the battery.



WARNING

Take a dead battery to a collection point.
Never dispose of one with household refuse.

Charging the battery

After a long lay-up(3-4 months), charge the battery. The charging current (in amperes) must not exceed 1/10th of the battery capacity (Ah).




The battery must not be fast-charged. The battery may only be charged using a special charger approved for maintenance-free batteries.

Maintenance

Although the battery is maintenance-free. Never leave the battery discharged. Keep the battery clean and dry and make sure that the connection terminals are firmly seated.

NOTES ON MAINTENANCE

Removing and installing the battery



CAUTION

The battery may only be connected or disconnected while the ignition is inactive.

- Turn off the ignition.
- Take off the plastic footrest cover (1).
- Remove the four screw(2) and open the inspection cover (3).

First disconnect the minus terminal (4, black cable).

- Disconnect the battery.
- Remove the battery.


Installation takes place in reverse order to disassembly.

When installing the battery, first connect the plus terminal (5, red cable).


The battery is maintenance-free. Do not try to open it.

NOTES ON MAINTENANCE

Headlight Version



Headlight Version 1 / 2 / 4



Headlight Version 5



Changing the bulb




NOTE

Use only tested, incandescent bulbs with the 'E' designation. Use of non-approved bulbs will void the operating license. Do not touch the bulbs with bare fingers. Hold bulbs with a clean, dry cloth when installing or removing them.

Low beam-high beam
bulb: **S2 12V 35W/35W**

- Turn off the ignition.
- Remove the screw and bolts (1).
- Take off the headlight cover (2).
- Disconnect the plug (3).
- Turn the indicator bulb holder (4) clockwise, take off the bulb holder.
- Press the indicator bulb and turn counter-clockwise, take off the bulb (5).

Installation takes place in reverse order to disassembly.





NOTE

While installation, align A to B.

NOTES ON MAINTENANCE

Headlight / Position light Version 3



Changing the bulb



NOTE

Use only tested, incandescent bulbs with the 'E' designation. Use of non-approved bulbs will void the operating license. Do not touch the bulbs with bare fingers. Hold bulbs with a clean, dry cloth when installing or removing them.

Low beam-high beam

bulb: **S2 12V 35W/35W**

Position light

bulb: **W5W 12V 5W**


- Turn off the ignition.
- Remove the screw and bolts (1).
- Take off the headlight cover (2).
- Disconnect the plug (3).
- Turn the indicator bulb holder (4) clockwise, take off the bulb holder.
- Press the indicator bulb and turn counter-clockwise, take off the bulb (5).
- Take off the bulb (6).

Installation takes place in reverse order to disassembly.





NOTE

While installation, align A to B.



NOTES ON MAINTENANCE

Position light Version 1 / 2 / 4 / 5



Changing the bulbs



NOTE

Do not touch the bulbs with bare fingers. Hold bulbs with a clean, dry cloth when installing or removing them.

Position light

bulb: **W5W 12V 5W**

Position light

- Turn off the ignition.
- Disconnect the position light from the arrow point.
- Remove the position light (1) in downward direction, then, pull out back the position light (1).
- Pull out the bulb (2) in the front.

Installation takes place in reverse order to disassembly.

NOTES ON MAINTENANCE

Front indicator



Changing the bulb



NOTE

Do not touch the bulbs with bare fingers.
Hold bulbs with a clean, dry cloth when installing or removing them.

Front indicator


- Remove the screw (1).
- Take off the cover (2).
- Press the indicator bulb and turn counter-clockwise, take off the bulb(3).

Installation takes place in reverse order to disassembly.

Bulbs: **12V 10W**

NOTES ON MAINTENANCE

Rear indicator and Tail / brake light




Rear indicator

- Remove the screws (1).
- Take off the cover (2).
- Remove the screws (3).
- Carefully remove the tail/brake light cover (4).
- Carefully remove the side light cover (6).
- Push the bulb (7) back and release it by turning to the left, remove the bulb.

Installation takes place in reverse order to disassembly.

Rear turn signal light:

BulbS: 12V 10W



Changing the bulb



NOTE

Do not touch the bulb with bare fingers. Hold bulbs with a clean, dry cloth when installing or removing them.


Tail / brake light

- Remove the screws (1).
- Take off the cover (2).
- Remove the screws (3).
- Carefully remove the tail/brake light cover (4).
- Push the bulb (5) back and release it by turning to the left, remove the bulb.

Installation takes place in reverse order to disassembly.


Tail / brake light

bulb: 12V 5/21W



NOTES ON MAINTENANCE

Check the headlamps




⚠ WARNING

Do not run the engine in an enclosed space (risk of asphyxiation).

Position the motorcycle on a level floor 5 m (measured from the headlamp) from a light coloured wall with a rider seated on the motorcycle and the tyres filled at the correct pressure.

- Measure the distance from the floor to the centre of the headlamp and mark the height on the wall with a cross. Draw a second cross 12 cm beneath the first cross.

Adjusting the headlamps






NOTE

If you have problems adjusting the headlamps, see a specialised dealer. An incorrect adjustment is punishable by law. Remember, you are responsible for the correct adjustment of the motorbike's headlamp.


- Start the scooter and run the engine.
- Activate the dipped beam.
- Use a screwdriver to adjust the screws (1) for the vertical and horizontal angle of the illuminated surface area of the road top for the headlamp.

NOTES ON MAINTENANCE

Fault diagnosis tester



1. Open the seat (2) with the ignition key(1). 2. Remove the screw (3), open inner cover (4). 3. Fault diagnosis tester connector (5).



4. Fault diagnosis tester (6). 5. The ignition key(7) at "↻" position. 6. Side (8) switch at horizontal position.

WARNING

44 When connect the fault diagnosis tester, ignition key(7) must be at "↻" position, side stand (8) at horizontal position.

TECHNICAL DATA

| | LJ50QT-8L |
|----------------------------|--|
| Engine type | LJ139QMB-3 |
| Construction: | One cylinder 4-stroke petrol engine |
| Piston displacement: | 49.6 cm ³ |
| Bore: | φ 39 mm |
| Stroke: | 41.5 mm |
| Compression ratio: | 10.5±0.2:1 |
| Cooling: | Fan air cooled |
| Maximum net power output: | 45 km/h: 2.2 kW / 8000rpm |
| Maximum net torque: | 45 km/h: 2.7 Nm / 7500rpm |
| Fuel consumption: | 45 km/h: 1.9 L/100km 25 km/h: 2.1 L/100km |
| CO ₂ emissions: | 45 km/h: 43 g/km 25 km/h: 48 g/km |
| Ignition system: | ECU |
| Spark plug: | NGK CR7HSA |
| Electrode gap: | 0.6-0.7 mm |
| Idle speed: | 2100±150 r/min |
| Air-filter: | Foam air-cleaner |
| Typ of starter: | Electric starter and kick starter |

TECHNICAL DATA

| | LJ50QT-8L |
|---------------------------|---|
| Power transmission | |
| Clutch: | Centrifugal type |
| Transmission: | CVT |
| | |
| Chassis | |
| Scooter version: | LJ50QT-8L |
| Front suspension: | Telescopic fork |
| Rear suspension: | Unit swing, hydraulic shock absorption |
| Wheels front: | Light metal (Alu) MT 2.50 × 10 |
| Wheels rear: | Light metal (Alu) MT 2.50 × 10 |
| Tires front: | 3.50-10 51J or 59P tubeless |
| Tires rear: | 3.50-10 51J or 59P tubeless |
| Tire pressure: | One Rider: Front: 1.75Kg/cm ² Rear: 2.00Kg/cm ² Two Rider: Front: 2.00Kg/cm ² Rear: 2.25Kg/cm ² |
| Brakes, front: | Disc brake ϕ 160 mm |
| Brakes, rear: | Drum ϕ 110 mm |

TECHNICAL DATA

| | LJ50QT-8L |
|---|---|
| Lubricants and operating fluids | |
| Fuel tank capacity: | 5.2±0.1 Liter |
| Fuel: | Euro IV version: E5 Other version: Unleaded fuel min. 95 Octane |
| Engine oil: | SAE 15W/40 mineral oil API (SG or higher) |
| Filling quantity: | 0.8 litres |
| Transmission oil: | Hypoid-oil SAE 85W-140 or SAE 80W-90 GL5 |
| Filling quantity: | 0.1 litres |
| Electrical Equipment | |
| Generator: | 12V 175W |
| Battery: | 12V 6Ah |
| Fuse: | 15A |
| Head light: | Low beam/High beam 12V 35W/35W |
| Front position light: | 12V 5W |
| Instrument lights Speedometer: | 12V 3W |
| Control lights indicator and high beam: | 12V 3W |
| Brake/rear light: | 12V 21/5W |
| Front turn signal light: | 12V 10W |
| Rear turn signal light: | 12V 10W |

TECHNICAL DATA

| | LJ50QT-8L |
|-------------------------------|----------------------------------|
| Dimensions and weights | |
| Overall length: | 1735 mm |
| Width across handlebars: | 660 mm without rear view mirror |
| Maximum height: | 1110 mm without rear view mirror |
| Wheel base: | 1210mm |
| Seat height: | 740mm |
| Dry weight: | 84 kg |
| Curb weight: | 88 kg |
| Max. permitted total weight: | 248 kg |
| Top speed: | 45 km/h or 25 km/h |

WARRANTY

Warranty conditions

In case of an occurring fault we will provide the customer with the following performances through the authorized dealer (seller) within the scope of its statutory warranty obligations:

1. Within warranty period, we will rectify any deficiencies caused by material or manufacturing faults through the authorized dealer (seller) by repairing or replacing the affected part according to the statutory warranty regulations. We may deny the requested repair or replacement of the faulty part if this would only be possible with disproportionately high costs. In this case we rectify the deficiency through the authorized dealer (seller) by applying the other possible type of subsequent fulfillment. If both types of subsequent fulfillment are only possible with unproportionately high costs, we deny the subsequent fulfillment all-together through the authorized dealer (seller). The customer is then entitled to legal claims. Replaced parts pass over into the possession of us.
2. The installation of spare parts within the scope of warranty does not extend the warranty period.
3. The warranty does not cover normal wear and tear caused by normal use as well as wear and tear caused by inappropriate handling and inappropriate use. Oxidation and corrosion are caused by environmental influences and are also not covered under warranty.
4. Warranty claims lodged by the customer will be rejected in case of: Manipulations to the motorcycle, installation of a different exhaust system, changes to the gearbox or secondary transmission ratio and installation of accessories or spare parts which have not been approved by us. Repairs carried out in workshops not authorized by us and the non-compliance with the maintenance intervals in the workshop of an authorized dealer will also cause the rejection of warranty claims.
5. When submit a warranty claim the customer must present the correctly filled in service book to the seller.
6. The following table gives the customer an overview of the average limits of the respective wear parts.

WARRANTY

List of wear parts

| Wear parts | Wear limits |
|--|---|
| Tires, houses, rims | Depending on riding style, load and tire pressure the wear limit may already be reached after only 500 km or even earlier. |
| Wheels, hubs | Depending on riding style, load and tire pressure the wear limit may already be reached after only 1500 km or even earlier. Check during each maintenance. Oxidation is a lack of maintenance! |
| Oils, air filter, leakage inspection on engine | During the first inspection, then with every maintenance interval(every 3000 km/6000 km). Check oil level before every ride. |
| Spring fork, spring strut | Cleaning / inspection during every maintenance. |
| Lamps, incandescent bulbs, electric system | Depending on road conditions / unevenness of the road surface the lifetime will be reduced, this may already occur after 500 km. |
| Brake linings, brake shoes, brake lines | Depending on riding style and load these may already be worn after 1500 km, in cross-country operation even earlier. |
| Rings, sealants, O-rings | Inspection during every maintenance and replace if necessary. |
| Radial seals on engine, gearbox, fork and wheels | Depending on road conditions and care wear may start after 500 km. Dirt reduces the lifetime. Do not clean with a high pressure cleaner! |
| Wheel bearings, steering bearings | Depending on road conditions and care wear may start after 1500 km. Soiling of the wheel hub reduces the lifetime. Check during each maintenance interval, do not clean with a high pressure cleaner! |
| Swing arm bearing | Depending on load and care after 1500 km, check with every maintenance. |
| Cables | Depending on care starting after 500 km. Check with every maintenance. |
| Coverings | Plastic parts will be damaged by caustic or penetrating cleaning agents or solvents. |

WARRANTY

List of wear parts

| Wear parts | Wear limits |
|--|---|
| Air cleaner, oil filter | With each maintenance interval. |
| Starter battery, batteries, fuses, starter brushes | Depending on ambient temperatures failures can be expected in the 6th month, when used for short rides even earlier. |
| Mirror glasses | Depending on ambient temperatures and care failures can be expected in the 6th month, in winter operation even earlier. Oxidation is a lack of maintenance! |
| Bowden cables, brake cables, throttle cables | Depending on use and care from the 6th month |
| Self-locking nuts, cotter pins locking plates bonded screw connections | During each maintenance interval or after unscrewing the nut or unlocking the lock. |
| Variomatic, CVT, rolls, belts | Depending on riding style and load these may be worn after 500 km. |
| Clutch linings / friction discs | Depending on riding style and load these may be worn after 500 km. |
| Pistons, cylinders, crankshaft, conrods, engine bearings | Depending on riding style, load and care these parts may be worn after 200 hours. When riding mainly with full throttle even earlier. |
| Spark plug | With each or every second maintenance interval. |
| Exhaust system, inspection of mountings | Depending on use and care from the 6th month, in winter and short distance operation even earlier. Oxidation is a lack of maintenance! |

INSPECTION PLAN

Please observe the following:

- During and after the warranty period all inspections should solely be performed by a specialised dealer approved by us.
- Observe the inspection intervals and have the specialised dealer confirm them on the guarantee certificate.
- Use only original spare parts.



CAUTION

In case of non-compliance, the warranty will become null and void.

The various activities carried out are listed on the inspection plan.

During the warranty period the following inspection intervals must be complied with:

At 1.000 km (1st service)
Every 3.000 km / or after 6 months
Every 6.000 km / or after 12 months

After the warranty period the inspection intervals specified in this manual must be applied as follows:

Every 3.000 km / 6 months
Every 6.000 km / 12 months



WARNING

For safety reasons, do not carry out any repair or adjustment activities to the scooter and chassis that exceed a closely restricted scope. Tinkering with safety-relevant parts could threaten the safety of yourself and third parties.

This applied especially to the exhaust system, carburettor, ignition system, fork column, brake system and lights.

Before starting work on the electrical system, disconnect the minus terminal of the battery.

INSPECTION PLAN

| I = Inspektion, cleaning, and adjustment R = Replacement C = Cleaning (replaced if necessary) S = Lubrication | | | | | | |
|--|------------------|---------------------------|---------------------------|---------------------------|---------------------------|-----------------------------|
| Component Assembly | Before each trip | 1 st service after 300 km | Every 1.000 km / 1 months | Every 3.000 km / 3 months | Every 6.000 km / 6 months | Every 12.000 km / 12 months |
| Air cleaner foam | I | I | | C | C | R |
| Oil filter (screen) | | C | | | C | C |
| Engine oil | I | R | Every 1000km R | | | |
| Fuel filter | I | I | | | I | R |
| Spark plug | I | I | I | I | | R |
| Ignition time | | I | I | I | | |
| Valve clearance | | I | I | | I | |
| Compression check | | | | I | | |
| Carburetor (Idle speed) | I | I | I | I | | |
| Throttle cable adjustment | I | I | I | I | | |
| Transmission oil | I | A | A | I | R | |
| Transmission check for leakage | I | I | I | I | | |
| Crankcase check for leakage | I | I | I | I | | |
| Crankcase ventilation | | I | I | I | | |
| Driving belt, tight weight | | | | I | I/R | |
| Clutch discs | | | | I | I/R | |

INSPECTION PLAN

| I = Inspektion, cleaning, and adjustment R = Replacement C = Cleaning (replaced if necessary) S = Lubrication | | | | | | |
|--|------------------|---------------------------|---------------------------|---------------------------|---------------------------|-----------------------------|
| Component Assembly | Before each trip | 1 st service after 300 km | Every 1.000 km / 3 months | Every 3.000 km / 3 months | Every 6.000 km / 6 months | Every 12.000 km / 12 months |
| Bolts and nuts (engine) | I | I | I | I | | |
| Compression teat | | | | I | | |
| Exhaust system | | I | I | I | | |
| Fuel tank, fuel hoses | I | I | I | I | | |
| Battery | I | I | I | I | | |
| Steering and bearings | I | I | I | I | | |
| Front and rear suspension | I | I | I | | I | |
| Shock absorption | I | I | I | | I | |
| Tire pressure | I | I | I | I | | |
| Brake function, brake pads | I | I | I | I | | |
| Brake fluid | I | I | I | I | | R / every 2 year |
| Main-and side stand | I | I | I | I/S | | |
| Bolts and nuts (chassis) | I | I | I | I | | |

MAINTENANCE CONFIRMATION

| | | | |
|--|---|---|---|
| <p>1.000 km/1 months 1st service dealer stamp:</p> <p>km..... date.....</p> | <p>After 3.000 km/6 months dealer stamp:</p> <p>km..... date.....</p> | <p>After 6.000 km/12 months dealer stamp:</p> <p>km..... date.....</p> | <p>After 9.000 km/18 months dealer stamp:</p> <p>km..... date.....</p> |
| <p>After 12.000 km/24 months dealer stamp:</p> <p>km..... date.....</p> | <p>After 15.000 km/30 months dealer stamp:</p> <p>km..... date.....</p> | <p>After 18.000 km/36 months dealer stamp:</p> <p>km..... date.....</p> | <p>After 21.000 km/42 months dealer stamp:</p> <p>km..... date.....</p> |

MAINTENANCE CONFIRMATION

New brake fluid
Yes no

km.....
date.....

Stamp, signature

New brake fluid
Yes no

km.....
date.....

Stamp, signature

New brake fluid
Yes no

km.....
date.....

Stamp, signature

New brake fluid
Yes no

km.....
date.....

Stamp, signature

Circuit diagram

